1 January 2016 By: KG



#### STOCKMAN STONEWORKS


#### OUTDOOR FIREPLACE KIT



Build Guide



"For ease of installation a cement pad is recommended." If concrete is not an option a pad of gravel will suffice. Insure to use a 1" Rock or comparable size, at least 2 inches thick, compacted on solid ground. Using a straight edge (i.e. 4' level or 2 x 4 Square) pick a starting side and begin leveling your blocks one at a time, using your straight edge as a guide.







Once your base is level, thoroughly brush off the top to ensure proper bonding. Clean your second layer blocks also and begin laying your second course, gluing all blocks. Gluing sides is not necessary. Again use your straight edge and square to keep everything plumb.


\*Important Note\* As you glue, gently tap block with your Dead blow to evenly distribute the glue between adjoining faces.


\*Important Note\* Take Caution, as freshly glued blocks will easily slide around until glue begins to set.




Again insure all blocks to be glued are thoroughly brushed and clear of dust. Begin at either corner and construct the back section first, gluing all touching blocks.













Lay the fire brick flush with the front block, leaving a hollow space in the back corner.




























Insure vertical portion of iron is 8 inches back from the front face of the forward most block.


















\* Remove any dust from Iron before gluing blocks to it.























\* Using your straight edge, draw guide lines to aid in proper offset.


Repeat for all four layers








































\*Again use guide lines to ensure proper alignment.






















# Final



Fireplace will be 7'11" tall by 4' wide and 4'4" long




#### **TOOLS**

SQUARE 4 FOOT LEVEL LADDER CAULK GUN DEAD BLOW HAMMER

#### Item List

Simplicity 12x8x4 221ea Simplicity Notch 2ea Simplicity 8x6x4 2ea
Simplicity 12x4x4 6ea Simplicity 8x8x4 6ea Simplicity 8x4x4 6ea
Simplicity 4x4x2 4ea Fire Brick 4.5x9 42ea Cut Fire Brick 3ea
Angle Iron 1ea PL Glue 10 Tubes



#### Item List

Hearth Cap 12x13x3 3ea Hearth Front Corner Cap 2ea Hearth Cap 12x8x3 7ea Hearth Rear Corner Cap 8x6x3 2ea

